



BULKHEAD LABELS

Table with columns: INSCRIPTION, QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for WT BHD FR No. 9, 13, 17, 22, etc.

PORTABLE FIRE EXT. LABELS

Table with columns: INSCRIPTION, QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for No. 1 LAB, FOCSLEDK, No. 2 A/C RM, etc.

MISC. LABELS

Table with columns: INSCRIPTION, QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for RIGHT RUDDER, LEFT RUDDER, etc.

PERSONAL HAZARDS

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for ON SILL TO STEP BELOW W.T. DOOR, etc.

OPERATING INSTRUCTION CONT.

Table with columns: INSCRIPTION, QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for VHF FM RADIO TELEPHONE OPERATION, etc.

Summary table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-14, SK-15, SK-16, etc.

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-17-1, SK-18, SK-19, etc.

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-20, SK-21.

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-22, SK-23, SK-24, SK-25.

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-26, SK-27, SK-28, SK-29, SK-30.

Table with columns: QTY, MATL, LTR SIZE, LOCATION, REMARKS. Includes entries for SK-31, SK-32, SK-33.