

Help Driving Long Cables

If you are trying to drive long cable and are getting telemetry errors, you can try sending the command \$MZ4 from the operator command line under the towfish diagnostic tab under the Sonar Interface. Other commands are \$MZ0-7.

This will have to be entered every time you turn on SonarPro.